


TOP AND CABINET PARTS

AUTOMATIC WASHER



TOP AND CABINET PARTS

For Models: LSQ9010PW3, LSQ9010PG3 (White/Grey) (Biscuit/Gold)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	3957165	Installation
		Instructions
	3955907	Feature Sheet
	3955869	Use & Care Guide
		Energy Guide
	8566203	Wiring Diagram

Following May Be Purchased

DO-IT-YOURSELF REPAIR MANUALS

	4313896	Manual, Washer Do-It-Yourself
2		Тор
	8543451	White
	8543452	Biscuit
3	62750	Spacer, Cabinet To
		Top (4)
4 5	357213	, ()
5		Cabinet
	63424	
	3954357	
6	62780	Clip, Top & Cabinet
_	0070040	& Rear Panel (2)
7	3976348	Cabinet –
0	2254644	Sound Damper (3)
8 10	3351614 9724509	Screw, Ground
10	8318084	Bumper, Lid (2) Switch, Lid
12	3357011	Screw, 10–16 x 1/2
13	355274	Screw, Id-10 x 1/2 Screw, Lid Hinge
13	333274	Mounting (4)
15	8559336	Hinge, Lid (L.H.)
16	91770	
18	8319539	Bearing, Lid
. •	00.000	Hinge (2)
19		Lid
-	8558398	White
	8558399	Biscuit
28	3390631	Screw,
		10-16 x 3/8 (4)
31	3955788	Cover, Dispenser
32	8519517	Dispenser, Bleach

CONTROLS AND REAR PANEL PARTS

CONTROLS AND REAR PANEL PARTS


Illus.	Part	DECORIDEION	Illus.	Part	DESCRIPTION	Illus.	Part	DECODIDEION
No.	No.	DESCRIPTION	No.	No.	DESCRIPTION	No.	No.	DESCRIPTION
1	3976300	Washer, Water Inlet Hose (4)	18	3979347	Valve, Water Inlet & Thermistor Assy.	41	8541669	Bucket, Drain Hose (Left Half)
		$(1-1/16 \times 5/8)$	20	694419	Mini-Buzzer	42	8541658	Bucket, Drain Hose
2 3	3400073		21	301958	Clamp, Hose			(Right Half)
3		Hose, Water	22	8317974	Hose, Vacuum	44		Knob, Timer
		Inlet (2)			Break		8544945	
	8571377	Blue Coupler	23	370450	Clamp, Hose		8544946	
	8571378	Red Coupler	24	387606	Break, Vacuum	45		Dial, Timer
4	9740848	Screw, 8-18 x 1/2	25	303294	Edge Protector		8544947	
5	8568314	Strap, Console (2)	26		Capacitor,		8544948	
6		Panel, Rear			Motor Start	46	8536939	Clip, Knob
7	62747	Pad, Rear Panel	27	8541667	Clamp, Hose	47		Knob, Control
8	8559374	Drain Hose	28		Clamp, Hose			(Includes Item 46)
		Assembly (Includes	30		Clamp, Hose		8544937	
		Items 27 & 28)	31		Clamp, Hose		8544938	
9	8557301	Timer, Control	32		Hose, Pump To Tub	49	388326	Screw, 8–18 x 1.25
		(60 Hz.)			(Includes #30)			(Panel to Top)
		(Motor Not A	33	8055003	Clip, Harness	50	62863	Screw, 10-16 x 3/8
		Service Part)			& Pressure Hose	51		Cap, End (R.H.)
10	3351614	Screw, Ground	34	8317975	Retainer, Harness		8271359	
11	90767	Screw, 8-18 x 3/8	35		Switch, Water		8271362	
12	3366845	Switch, Water Level			Temperature (ATC)	52	8541672	U-Bend,
13	8544893	Bracket, Control	36	3400818	Screw, Timer			Drain Hose
14	661661	Cord, Power			Mounting	59	8539874	Shield, Suds
		(Includes Item 15)	37	3949180	Switch, Řotary	60	3957274	Harness, Wiring
15	3952821	Strain Relief,	38		Switch, Rotary			(For Detail See
		Power Cord	39		Panel, Console			Pages 9 & 10)
16		Cap, End (L.H.)			(Includes Item 40)	61		Cable Tie
	8271365			3956588		62	8519200	Support, Rear
	8271368	Biscuit		3956589				Panel
17	8318046	Clip, Capacitor	40	3400985	Medallion			

AGITATOR, BASKET AND TUB PARTS


AGITATOR, BASKET AND TUB PARTS For Models: LSQ9010PW3, LSQ9010PG3 (White/Grey) (Biscuit/Gold)

IIIus. No.	Part No.	DESCRIPTION
1 2	63580 358237	Dispenser Screw & Washer (5/16–24 x 1)
3 4	3363003 3951632	Clothes Mover Agitator
5	8528150	Tub Ring & Gasket
6	3976308	Gasket, Tub Ring
7	3354845	Clip, Agitator
8	3355921	Washer, Agitator
9	3951682	Cam, Driven
10	3366877	Dog, Agitator Clutch (4)
11	3952374	Bearing-Driven
12	21366	Nut, Spanner
13	8526016	Basket & Balance Ring
14	2219077	Clip, Pressure Switch Hose
15	8519788	
16	63849	9
17	389140	Block, Basket Drive
18	383727	Gasket, Centerpost
19	3347780	Hose, Pressure Switch
20	3951744	Agitator (Complete)
22	3951608	Spacer, Thrust
23	3354733	Cap, Barrier
24	3348855	Seal, Inner Cap
26	3949550	Washer


MACHINE BASE PARTS



BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS



WIRING HARNESS PARTS
For Models: LSQ9010PW3, LSQ9010PG3
(White/Grey) (Biscuit/Gold)



WIRING HARNESS PARTS

For Models: LSQ9010PW3, LSQ9010PG3 (White/Grey) (Biscuit/Gold)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1 2 3 4 5	388498 3347812 3352501	Clip, Harness Clip, Harness Clip, Harness Clip, Harness Clip, Harness	10	353424 62505	Plug, Terminal (3–Way) (Power Cord) (Use Term.94613) Block, Disconnect	17 18 19	3349494	Receptacle (6–Way) (Use Term. 94613) Connector, Etc E.T.C. Control
6 7	3390496	Clip, Harness Retainer, (Suds Models)	12	3347243	(Motor 2 Speed) (Use Term.352088) Block, Disconnect	20		Connector (T.P.A.) (3–Circuit) (Lid Switch)
8	3948614 352089	Timer, Block Disconnect White Black	13 14		(Use Term. 352088) Protector Connector	21	3360056	Connector (T.P.A) (3–Circuit) (Pressure Switch)
9	62889	Receptacle, Terminal (3–Way) (Lid Switch) (Use Term.94613) Or 94614.)	15 16	3352944 3390423	(2-Way) (Use Term.94614) Clip, Harness Block, Disconnect (12-Way) (Timer) (Use Term. 94613)	22		Block, Connector Cold Valve Hot Valve

FOR COMPLETE WIRING HARNESS REFER TO CONTROL AND REAR PANEL PARTS PAGE

WH2I

BRAKE AND DRIVE TUBE PARTS

For Models: LSQ9010PW3, LSQ9010PG3 (White/Grey) (Biscuit/Gold)



Illus. No.	Part No.	DESCRIPTION			
1	388952	Brake And Drive Tube (Complete)			
2	62658	Ring, Thrust			
2	356427	Seal, Drive Tube			
4	64027	Tube, Basket Drive (Includes Illus. 3, 4, 5 & 9)			
5	64035	Ring, Retaining			
6	64232	Shoe, Brake (2)			
7	62703	"T" Bearing, Spin Tube			
8	3353956	Cap, Brake Spring (2)			
9	387806	Spring, Brake			
10	3355360	Sleeve, Brake Spring			
11	661516	Cam, Brake Release			
12	63022	Sleeve, Cam			
13	64194	Driver, Brake Cam			
14	90368	Ring, Retaining			
	FOLLOWING PARTS NOT ILLUSTRATED				


285208 Lubricant (Use Only In Brake Shoe Assembly On Roller & Pin)


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

GEARCASE PARTS

		1	
	22		
2		Illus. Part No. No.	DESCRIPTION
3		110. 110.	DEGORII HON
		1 3360630	Gearcase (Complete)
5 6	23	2 285202 3 3349985	Cover, Gearcase
			Seal, Gearcase Cover
<u> </u>	7 — 24	4 285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)
i 8 —— 💆	25	5 63320	Pinion, Spin (Includes Illus. 25)
! 9	26	6 356427	Seal, Spin Pinion
1 10		7 389387	Shaft, Agitator (Complete)
9		8 90369 9 62677	Ring, Retaining (2) Retainer, Spring
11		10 62676	Spring, Agitate
		11 63273	Gear, Agitate (Includes 15 and 29)
12		12 62619	Washer, Agitate Gear
13		13 62580	Cam Follower (Includes 14)
14		14 62581	Cam, Agitate
		15 285509	(Includes 13) Shaft, Agitator (Includes 11 and 29)
		16 62618	Washer, Cam Thrust
		17 16018 18 85529	Bearing, Thrust Ball, Bearing
	L — — — — — — — — — — — — — — — — — — —	19 389230	Bottom and Pinion, Gearcase
15	27	21 285352 22 3351614	Seal, Thrust Plug
		22 3331014	Screw, Gearcase Cover, Mounting (8)
16	28	23 3362552	(10–24 x 3/8) Ring, Retaining
29		24 285735	Washer Kit, Thrust
8	i	25 62570 26 388253	Gear, Spin Neutral Assembly
17		27 3349296	Rack, Connecting
18	19	28 62621 29 388815	Actuator, Shift Washer,
			Intermediate
21			
	4		
	GC-215-C		


WATER SYSTEM PARTS





Illus. No.	Part No.	DESCRIPTION
1	285442	Connector Kit,
		Plastic Drain
		Hose
2	285321	Sleeve Kit,
		(Contains 2
		Sleeves)
3	370447	Clamp, Hose
4	16272	Connector,
		Straight
5	285320	Siphon Break
		Kiṫ
		(Not Included)
6	65349	Clamp, Hose
7	367031	Drain Protector
		(Not Included)
		,

MISCELLANEOUS PARTS



Illus.	Part	
No.	No.	DESCRIPTION
1	3957361	Miscellaneous
		Parts Bag
2	3976300	
		Inlet Hose (4)
		(1-1/16 x 5/8)
3	3359452	Nut, Lock (2)
		(3/8–16)
4	389102	Foot, Front (2)

OPTIONAL PARTS (NOT INCLUDED)

For Models: LSQ9010PW3, LSQ9010PG3 (White/Grey) (Biscuit/Gold)

Illus. Part

No. No. DESCRIPTION

PAINT, TOUCH-UP (1/2oz.)

72017 White 4392899 Biscuit

PAINT, PRESSURIZED SPRAY

(12 oz.)

350938 Primer, Gray 350930 White 4392901 Biscuit

PAINT, BULK (1 qt.)

799344 White (Uncut) 4392900 Biscuit (Uncut)

OIL

350572 Oil, Gearcase (16 Oz.)

LUBRICANT

285208 Lubricant (Use Only in Brake Shoe Assembly On Roller and Pin)

SEALER

285195 Sealer, Gasket (.20 Fl. Oz.) (6 ml)

ACCESSORY PARTS

367031 Drain Protector 285320 Siphon Break Kit